
WALL TREE SET UP INSTRUCTIONS





(fig.1)

*AA battery not included for motor (6.)

** It's not uncommon for chains to disconnect during shipping.

Extra chains and connectors are provided for this reason (2., 3., 4. in fig.1)



WALL TREE TOPPER ASSEMBLY

You can pick from the mirror or white star pieces or a combo of both. Match up desired 3 pieces, align center holes, and nail (1.2) into the wall 6.5 feet from floor. Then follow instructions below.

1

Attach metal tree ring (5.) to tree topper nail in wall.

Place motor (6.) on top of second acrylic tree ring. See fig.2

3

Attach mirror ball to the motor's bottom hook so the ball hangs directly above the spotlight.

1.0





For troubleshooting set up, please see page 11.

If you purchased an undecorated tree, the mirror ball with rotator can be purchased separately.

All of us at Modern Christmas Trees want you to have the best experience with your new tree. If you have any questions or concerns please email:

care@modernchristmastrees.com

